

					AUX16								
		USB			1	2	3	4	5				
					6	7	8	9	10				
					AUX15	AUX14	AUX13	AUX12	AUX11		1	37	INJ3
											2	38	
											3	39	
											4	40	
											5	41	
											6	42	
											7	43	
											8	44	
											9	45	
											10	46	
											11	47	
											12	48	
											13	49	
										AUX4	14	50	AUX8
										AUX3	15	51	AUX7
										AUX2	16	52	AUX6
										AUX1	17	53	AUX5
											18	54	
											19	55	
										IGN4	20	56	IGN8
										IGN3	21	57	IGN7
										IGN2	22	58	IGN6
										IGN1	23	59	IGN5
										12V	24	60	
											25	61	
											26	62	
											27	63	
											28	64	
										12V	29	65	
										INJ8	30	66	
										INJ7	31	67	
										INJ6	32	68	
										INJ5	33	69	
										INJ4	34	70	
										GND	35	71	
										INJ2	36	72	INJ1